




**Cleaning Glasses in the dishwasher for measurement.** Revised: 9-12-2011

Follow these instructions to clean glasses for measurement in your dishwasher. You should be able to clean more than 50 pairs at once. Start by filling up the top part of your dishwasher with glasses.

Place glasses in rack as shown.




Continue adding glasses inserting them into the fingers of the rack.



Close up view of the glasses.



Fill all the "Fingers" of the rack with glasses.



Add a second level to maximum finger length.



Keep adding until the tray is full.



Now fill the bottom part of your washer with glasses.

Add 3-4 pairs to silverware holder opening.



Fill bottom tray the same as the top tray.



Layer pairs of glasses as before.



Do this until the bottom rack is full.



Now add detergent and be sure you add "Jet-Dry". Jet-Dry will remove any of the streaking from the glasses. Wash the glasses just like you would wash your dishes. When the cleaning is finished, pack them as shown in the **Preparing the Glasses for Measurement** document.

Some very old glasses will not make it through the dry cycle. If so, just throw them away.

THANK YOU so much for your help in the eyeglasses ministry.

Your brother in Christ, Holland Kendall